Canon

SELPHY CP780

COMPACT PHOTO PRINTER

Printer User Guide

ENGLISH

- Make sure you read this guide before using the printer.
- Store this guide safely so that you can use it in the future.

CDI-E394

Share Your Memories with SELPHY

Compact, Stylish, Powerful!

Save your precious moments with SELPHY.

What You Can Do with Your SELPHY

Necessary Preparations to Use SELPHY ____ pp. 8 – 12

Compatible Memory Cards and Images That Can Be Printed ____ p. 13

Print a Single Image ____ p. 14

Print All Images ____ p. 16

Various Prints ____ pp. 18 – 20

Print Images from a Computer ____ pp. 21 – 25

INDEX

Package Contents ____ 4

Ink and Paper (Sold Separately) ____ 4

Read This First ____ 5

Conventions Used in this Guide ____ 5

Getting Familiar with SELPHY ____ 6

For Your Safety ____ 7

Setting Up SELPHY ____ 8

Getting Started ____ 9

Setting the Display Language ____ 12

Printing Images ____ 13

Printing a Variety of Images ____ 18

Printing from Your Computer ____ 21

Printing From Your Digital Camera ____ 26

Printing Images Using Camera Specified Settings (DPOF Print) ____ 27

SELPHY Settings ____ 28

Using the Battery Pack ____ 29

Printing From Your Mobile Phone ____ 30

Troubleshooting ____ 31

Handling Precautions ____ 33

Specifications ____ 34

Package Contents

Check if the following items are included in your printer package, using the ☐ check boxes. If anything is missing, contact the retailer where you purchased the printer.

☐ SELPHY Printer Unit

☐ Compact Power Adapter CA-CP200 W



☐ Power Cord

☐ Paper Cassette (Postcard Size)

☐ Paper Cassette (Card Size)*

☐ CD-ROM: COMPACT PHOTO PRINTER Solution Disk

☐ Printer User Guide (This Guide)

☐ Warranty Card

* Card size paper cassette may not be supplied depending on region.

Ink and Paper (Sold Separately)

Before using the printer, be sure to purchase a Color Ink cassette/Paper Set separately.

Color Ink Cassette/Paper Set			Necessary Paper Cassette
Product Name	Paper Size	Number of Possible Prints	
Color Ink Cassette/Paper Set KP-36IP (Postcard)	Postcard Size	36	Paper Cassette PCP-CP300 (Included with SELPHY)
Color Ink Cassette/Paper Set KP-72IN (Photo Paper)		72	
Color Ink Cassette/Paper Set KP-108IN (Photo Paper)		108	
Color Ink Cassette/Paper Set KC-36IP	Card Size	36	Paper Cassette PCC-CP300*1
Color Ink Cassette/Label Set KC-18IF (Full-page labels)		18	
Color Ink Cassette/Label Set KC-18IL (8-label sheets)		18	
Color Ink Cassette/Paper Set KW-24IP	Wide Size	24	Paper Cassette PCW-CP100*2

*1 Some accessories may not be available depending on the region. Please purchase separately.

*2 Please purchase the paper cassette in addition to the dedicated Color Ink/Paper Set.

Read This First

Warning Against Copyright Infringement

The images printed with this product should be intended for personal use. Do not print images that infringe upon copyright laws without the prior permission of the copyright holder.

Warranty Limitations

This product's warranty is only effective in the country of sale. If a problem arises while the printer is in use abroad, please return it to the country of sale before proceeding with a warranty claim to a Canon Customer Support Help Desk.

Conventions Used in this Guide

- This printer will be referred to as "SELPHY" or "printer".
- The various types of memory cards that can be used in this printer are collectively referred to as "memory cards".
- Icons are used in the text to represent SELPHY's buttons.
- Language that displays on the screen appears inside [ ] (square brackets).
- Buttons are represented by the following icons:



- ⓘ : Things you should be careful about.
- ✎ : Supplemental information.
- (p. XX) : Reference pages. "XX" stands for page number.
- This chapter assumes all functions are at their default settings.

Getting Familiar with SELPHY

Learn more about the parts names and displays on the screen in this section.

Components Guide



Information Displayed on the Screen


SD
Currently used memory card slot
Paper orientation
Print Settings (p. 18)
Borders, Page Layout, Date, Correct Red-Eye, My Colors, Image Optimize, (Settings that are not available are grayed out)
File Number
050-0024
P 4×6/10×15
1
1
Total number of prints (Number of sheets required)
Installed color ink cassette type (Postcard Size is used in this example.)
Number of copies of the displayed image

For Your Safety

- Before using SELPHY, please ensure that you read this "For Your Safety" section. Always ensure that SELPHY is operated correctly.
- The safety precautions noted on the following pages are intended to prevent injuries to yourself and other persons, or damage to the equipment.
- Be sure to also check the guides included with any separately sold accessories you use.

⚠ **WARNING** Denotes the possibility of serious injury or death.

⚠ **CAUTION** Denotes the possibility of injury.

CAUTION Denotes the possibility of damage to the equipment.

⚠ WARNING

This Printer

- **Do not attempt to disassemble or alter any part of the equipment in a way that is not expressly described in this guide.**
- **To avoid the risk of injury, do not touch the interior of the printer if it has been dropped or otherwise damaged.**
- **Stop operating the printer immediately if it emits smoke, a strange smell, or otherwise behaves abnormally.**
- **Do not use organic solvents such as alcohol, benzine, or thinner to clean the equipment.**
- **Do not allow liquids or foreign objects to enter the printer.**
  This could result in electrical shock or fire.
  Should this occur, immediately turn the printer's power off and unplug it.

- **Use only recommended power sources.**
  Using other power sources could result in electrical shock or fire.

- **Do not touch this printer or the power plug during thunderstorms.**
  This could result in electrical shock or fire. Immediately stop using the equipment and distance yourself from it.

Power (Compact Power Adapter)

- **Store this equipment out of the reach of children and infants.**
  Mistakenly putting the power cord around a child's neck could result in asphyxiation.

- **Use only recommended power sources.**
- **Do not cut, damage, alter or place heavy items on the power cord.**
- **Unplug the power cord periodically and wipe away any dust and dirt that has collected on the plug, the exterior of the power outlet, and the surrounding area with a dry cloth.**
- **Do not handle the power cords with wet hands.**
  This could result in electrical shock or fire.

Other Warnings

- **Do not play the supplied CD-ROM(s) in any CD player that does not support data CD-ROMs.**
  Playing the CD-ROM(s) in an audio CD player (music player) could damage the speakers. It is also possible to suffer hearing loss from listening with headphones to the loud sounds of a CD-ROM played on a music CD player.

⚠ CAUTION

- **Do not stick any part of your hand into the printer interior.**
  This could lead to injury or damage the printer.

- **Do not use the power cord for any other equipment except this printer, use it beyond its rated capacity or voltage, or leave the plug partially inserted into a power outlet.**
  This could result in electrical shock or fire.

- **Avoid using, placing or storing the printer in the following places.**
  -Places subject to strong sunlight.
  -Places subject to temperatures above 40° C (104° F).
  -Humid or dusty areas.
  Electrical shock or heating could result in burn, injury or fire. Heat may cause deformation of the printer's casing.

- **Do not allow metallic pins to touch or allow dust to collect on the power plug.**
  This could result in electrical shock, fire, malfunction or other damage.

CAUTION

- **Unplug the power cord from the power outlet when you are not using the printer.**
- **Do not use the compact power adapter if it is covered by clothing.**
  If connected for a long period, this could result in overheating, deformation of the casing or fire.

Setting Up SELPHY



- Place SELPHY on a stable and even surface, such as a table. Never place it on an unstable or tilted surface.
- Keep SELPHY at least 1 m (3 ft.) from devices emitting electromagnetic waves or strong magnetic fields.
- Make sure there is at least 10 cm (4 in.) of free space around SELPHY.
- Make sure there is free space of at least the length of the paper behind SELPHY. (During printing the paper will pass in and out.)

- Never place SELPHY close to motors or other devices that generate strong electromagnetic fields. This may damage or cause the printer to malfunction.
- Do not place near television or radio. This may cause the printer to malfunction.

The LCD monitor may be covered with a thin plastic film for protection against scratches during shipment. If so, remove the film before using SELPHY.

Getting Started

Preparations for printing images. The Postcard size Color Ink Cassette/Paper Set (separately sold) (p. 4) will be used as an example.

Preparing the color ink cassette



Check the color ink cassette

- Check that the paper size and the size shown on the color ink cassette (Card Size, Postcard Size etc.) match.
- Check that the ink sheet is taut with no slack. If the ink sheet is slack, push and turn the sprocket as shown in the illustration.

Do not touch or pull on the ink sheet. Do not touch the color ink cassette with wet or sweaty hands. You may not be able to print if the ink sheet is damaged, dirty or wet.

Preparing the Paper Cassette

1

Check the paper size.

- Check that the prepared color ink cassette and the size shown on the paper cassette (Card Size, Postcard Size etc.) match.

2



Open the lid.

- There are two steps to open the lid. Open the outer lid ① first, then open the inner lid ②.
- For Wide size paper cassette (sold separately), open the outer lid first, then slide the inner lid in the direction of the OPEN arrow to open it.

3



Set the paper.

- Set the paper into the paper cassette that you prepared in Step 1.
- You can place up to 18 sheets in the paper cassette (up to 12 for Wide size). Inserting 19 or more sheets (13 or more for Wide size) may damage the printer or cause malfunction.
- Hold the paper stack as shown in the illustration, with the shiny side facing up. Do not touch the print side (shiny side) of the paper with your fingers. Doing so may prevent you from making clean prints.
- When a protective sheet is present, remove it and only set the paper stack into the cassette.



- When making postcard size prints that have a section for pasting a stamp, insert the paper so that the stamp section is facing the inner lid (as shown in the illustration).

4

Close the lid.

- Close the inner lid until it clicks into place. Leave the outer lid open during printing.
- For Wide size paper cassette (sold separately), close the inner lid first, then slide the inner lid until it clicks to the opposite direction of the OPEN arrow.

- Always use the paper specific to SELPHY CP series printers included in the genuine Canon brand Color Ink Cassette/Paper Sets. Use only dedicated paper. Regular printing paper, regular postcards, or paper specified for use in SELPHY ES series printers cannot be used.
- Never do the following, as it may lead to failure or cause the printer to malfunction:
  - mistakenly reversing the paper (the shiny side is the print side)
  - bending or separating the paper at the perforations
  - using label sheets that have begun to peel or label sheets with portions peeled back
  - writing on a sheet before printing
  - printing on already printed paper
  - reusing a spent color ink cassette
- Do not touch the springs of the paper cassette.
  If the springs are bent or deformed, paper will not feed correctly into SELPHY.
- Do not touch the print surface (shiny side), scratch it or touch the paper with wet hands. Prints will not be desirable if the print surface becomes dirty or wet.



Installing the color ink cassette and the Paper Cassette

1



Open the covers.

- Open the covers for the color ink cassette and paper cassette compartments.

2



Insert the color ink cassette.

- Insert the color ink cassette as shown in the illustration until it clicks and locks.
- Close the compartment cover.

3



Insert the paper cassette.

- Make sure that the outer lid is open. (p. 10) Insert the paper cassette as shown in the illustration all the way into the compartment.

Connecting SELPHY

1



Plug the cord into SELPHY.

- Fully insert the adapter plug into SELPHY.

2



Connect the power cord.

- Connect the power cord to the compact power adapter, then plug the other end into a power outlet.

Do not handle the power cords with wet hands.

Setting the Display Language

You can change the language displayed in the LCD monitor menus and messages.

1





Display the setting screen.

- Press the ▢(MENU) button.
- Press the ▲ or ▼ buttons to select [Printer Setup], then press **OK**.

2



Display the language setting screen.

- Press the ▲ or ▼ buttons to select [Language].
- Press **OK**.

3



Select a language.

- Press the ▲, ▼, ◀ or ▶ buttons to select a language, then press **OK**.
- Pressing the ▢(BACK) button twice will restore the image display screen.

Printing Images

You can print images on a memory card when it is inserted into SELPHY.

Compatible Memory Cards

Memory Card Slots (SELPHY memory card slots)	Memory Cards That Can be Used Without an Adapter	Memory Cards That Require an Adapter (commercially available)
CF/microdrive	● CompactFlash Card ● Microdrive	● xD-Picture Card*1
SD/miniSD/MMC+ RS-MMC	● SD Memory Card ● miniSD Card ● SDHC Memory Card ● miniSDHC Card ● MultiMediaCard ● MMCplus Card ● HC MMCplus Card ● MMCmobile Card ● RS-MMC Card*2	 ● microSD Card ● microSDHC Card ● MMCmicro Card
MS/MS Duo	● Memory Stick ● Memory Stick PRO ● Memory Stick Duo ● Memory Stick PRO Duo	● Memory Stick micro

*1 Purchase the CompactFlash Card Adapter for xD-Picture Card. *2 Reduced-Size MultiMediaCard

- For memory cards requiring an adapter, be sure to first insert the memory card into the adapter before inserting the adapter into the appropriate card slot. If you insert the memory card into a card slot without using an adapter, you may not be able to remove the memory card from SELPHY.
- Use a memory card formatted in the device used for taking the images. A memory card formatted in the computer may not be recognized.

Refer to the user guide included with your memory card and adapter for handling instructions.

Images that Can Be Printed

The following image types can be printed with SELPHY.

- JPEG type data conforming to the Exif standard.

Irregularly sized images, or images that have been edited on a computer may not display or print properly.

Selecting and Printing Images

You can select an image and specify the number of copies for printing. SD memory cards will be used as an example.

1



Turn on the power.

- Press and hold the ⏻ button until the screen on the left displays.
- To turn the power off, press and hold the ⏻ button again until the screen on the left displays.

2



Insert a single memory card into the slot.

- Insert a single memory card containing the images you want to print all the way into the appropriate memory card slot.
- ▶ The screen in Step 3 appears.

3

4

Number of copies of the displayed image

Total number of prints (Number of sheets required)

Select an image.

- Press the ◀ or ▶ buttons to select an image to print.
- If you hold the ◀ or ▶ buttons pressed, the display jumps by 5 images.

Select the number of copies.

- Press the ▲ or ▼ buttons to select a value.
- If you hold the ▲ or ▼ buttons pressed, the number increases or decreases by 5 copies.
- You can specify 99 copies per image (or a total of 999 copies).
- To print another image, repeat Steps 3 and 4.

5



Print.

- Press the 🖨 button to start printing.
- During printing, the paper will pass in and out from the back of SELPHY several times. Do not touch the paper until printing has finished and the printed sheet collects on the print output tray (on top of the paper cassette).
- Do not let 19 or more printed sheets (13 or more for Wide size) collect on the print output tray.
- To cancel printing, press the ▢(BACK) button.

6



Insert the paper.

- When the paper is depleted, remove the paper cassette from SELPHY.
- Refill new paper, and reinsert the paper cassette into SELPHY (p. 11).

7



Change the color ink cassette.

- When the color ink is depleted, open the color ink cassette compartment cover and move the lock as shown in the illustration. The color ink cassette will be ejected.
- Insert a new color ink cassette (p. 11).

Never pull out the paper cassette, open the color ink cassette cover or remove the memory card during printing or directly after turning on the printer. This may cause the printer to malfunction.

When the total number of copies (p. 14) is set to 0 and you press the 🖨 button, the currently displayed image will print once.

Printing All Images

You can print all images on a memory card at once.

1



Display the menu.

- Press the ☐(MENU) button.

2



Display the setting screen.

- Press the ▲ or ▼ buttons to select [Print All Images], then press **OK**.

3



Select the number of copies.

- Press the ▲ or ▼ buttons to set the number of copies.
- You can specify 99 copies per image (or a total of 999 copies).

4



Print.

- Press the 🖨 button to start printing.
- To cancel printing, press the ☐(BACK) button.

Cleaning Up After Printing

After you finish printing, follow the steps below for cleaning and storing SELPHY.

- Turn the power off (p. 14).
- Unplug the power cord from the power outlet and disconnect the adapter plug from SELPHY.
- If the compact power adapter is hot, wait until it has cooled down before you store it.
- Remove the memory card and paper cassette and close the paper cassette compartment cover. Keep the remaining paper inside the cassette and store the paper cassette so that it is protected from dust and light. Also, do not unpack paper before it is used, and keep it in a dark place.
- Keep the color ink cassette inside SELPHY. If you store the color ink cassette outside SELPHY, put it in a bag so that dust does not stick to the sheet.
- Store SELPHY flat so that dust does not enter.

If dust enters SELPHY and sticks to the paper or color ink, print quality deteriorates.

Storing the Printed Photos

- When both sides of a print have perforations, you can remove the edges by bending them.
- Use an oil-based pen to write on prints.
- Avoid storing photos in places with high temperatures (40°C/104°F or higher), places with high humidity or dust, or places subject to direct sunlight.
- Avoid actions that may result in color change, color fading or color bleeding, such as the following: Sticking any type of adhesive tape on a print surface, allowing print surfaces to come into contact with vinyl or plastic, applying alcohol or other volatile solvents to a print surface, leaving print surfaces tightly pressed against other surfaces or objects for prolonged periods.
- If you wish to mount prints in an album, select an album with photo covers made of nylon, polypropylene or cellophane.

Color may change over time or depending on storage conditions. Canon assumes no liability for color changes.

Printing a Variety of Images

You can use various printing features, such as imprinting the shooting date or adjusting the color of an image. You even do not need to repeat the settings for each image because once the settings are made, they are applied for all images.

Inserting the Date

You can print images with the shooting date showing on the lower right. Since the date printed will be the date the image was recorded by the camera, it cannot be changed on SELPHY.

1



Display the menu.

- Press the ▢(MENU) button.

2



Display the setting screen.

- Press the ▲ or ▼ buttons to select [Print Settings], then press **OK**.

3



Setting [Date] to [On].

- Press the ▲ or ▼ buttons to select [Date] .
- Press the ◀ or ▶ buttons to select [On] .
- Pressing the ▢(BACK) button twice will restore the image display screen.
- Select an image and print (p. 14).
- ▶ The printed image will show the shooting date on the lower right.



- You can change the ordering for the date in [Date Format] in [Printer Setup] (p. 28).
- Depending on the layout (p. 19), imprinting the date may not be possible. Select [Info Display] and set to [On]. Check the print settings that are now displayed (p. 28).

Various Functions

In addition to the date imprint feature, SELPHY has a variety of other functions.
*Default setting

Correcting Red Eyes and Printing (Correct Red-Eye)

- Correct images with red-eye.
- Off* / On

- Red-eye may not be automatically detected or optimally corrected when faces appear extremely small, large, dark or bright in relation to the overall image, with faces turned to the side or at a diagonal, or faces with a portion hidden.
- Portions other than the eyes may be mistakenly corrected.
  Set [Correct Red-Eye] to [On] only when printing images with red-eye.
- If you set [Page Layout] to [Index], red-eye will not be corrected.

Changing the Color Tone and Printing (My Colors)

- You can change the look of an image to sepia or black and white.

Off*	–	Positive Film	Intense, natural colors like those obtained with positive film
Vivid	Emphasizes the contrast and color saturation for a vivid impression	Sepia	Tones the image into sepia
Neutral	Tones down the contrast and color saturation for neutral hues	B/W	Black and white

Choosing a Layout and Printing (Page Layout)

- Set the number of images that you want to print on one sheet. The number of images that you specified (p. 14) will be printed in the layout set.
- Set the layout to 8-up when using color ink cassette/label set KC-18IL (8-label sheet) (p. 4).

1-up*	–	8-up	Print eight images on one sheet
2-up	Print two images on one sheet	Index	Print as index
4-up	Print four images on one sheet		

- The image position cannot be specified.
- Depending on the layout, other settings may be canceled. Select [Info Display] and set to [On]. Check the print settings that are now displayed (p. 28).
- If you select [Print All Images] in [Index] (p. 16), you can print all images on a memory card as an index print.

Getting the Best Results with Auto Correction (Image Optimize)



- Dark images will be adjusted to the proper brightness. At the same time, people's faces, and overall brightness will be adjusted.
- Off / On*

Some images may not be adjusted correctly.

Printing With or Without Border (Borders)



- Set images to print with or without a border.
- Borderless* / Bordered

Setting Various Functions

Set the functions introduced in the "Various Functions" section. (p. 19) You can set various functions using the same operation.

1



Display the settings screen.

- Press the ▢(MENU) button.
- Press the ▲ or ▼ buttons to select [Print Settings], then press **OK**.

2



Select the item and change the settings.

- Press the ▲ or ▼ buttons to select an item.
- Press the ◀ or ▶ buttons to change the settings, then press the ▢(BACK) button to make the setting.
- Pressing the ▢(BACK) button again will restore the image display screen.

Printing from Your Computer

If you connect your computer to SELPHY and use the supplied software, you can view images in a list while using various printing functions that cannot be done with just SELPHY alone. Following the audio guidance will allow inexperienced computer users to print easily.

Select favorite images from the list and print

- You can select images you wish to print from a list, and print them all at once.

Print with decorations

- You can add frames or stamps to your images and print. You can also add text to your images and print.

Print calendars

- You can add calendars to your prints.

Items to Prepare

- SELPHY and Computer
- Supplied CD-ROM (COMPACT PHOTO PRINTER Solution Disk) (p. 4)
- USB Cable (Commercially available) (SELPHY terminal requires Type B connector)

System Requirements

Even though these are recommended system requirements, not all computer functions can be guaranteed.

	Windows	Macintosh
OS	Windows Vista (including Service Pack 1) Windows XP Service Pack 2, Service Pack 3	Mac OS X v10.4 – v10.5
Configuration	The above OS should be pre-installed on computers with built-in USB ports.	
CPU	Pentium 1.3 GHz or higher	PowerPC G4/G5 or Intel Processor
RAM	Windows Vista: 1 GB or more Windows XP: 512 MB or more	512 MB or more
Interface	USB	
Free Hard Disk Space	80 MB or more	100 MB or more
Display	1,024 x 768 pixels or more	1,024 × 768 pixels or more

- You need a CD-ROM drive to install the software.

Install and start the software

Windows XP and Mac OS X 10.5 are used for these explanations.

1

Install the software.

Windows

- Place the CD-ROM in the computer's CD-ROM drive and click [Easy Installation] when the screen on the left appears.
- Follow the onscreen instructions to proceed.

▶ Proceed with the installation to display the screen on the left.

Macintosh

- Place the CD-ROM in the computer's CD-ROM drive and double-click .
- When the screen on the left appears, click [Install] and follow the onscreen instructions to proceed.
- When the install finishes, click [Finish] to complete the installation.

2

Prepare SELPHY.

- Turn off SELPHY and remove the memory card.
- Insert a paper cassette that contains paper, and a color ink cassette into SELPHY.
(pp. 9 – 11)

3



Commercially available USB cable

Connect SELPHY to a computer.

- Use the USB cable to connect SELPHY to the computer.
- Refer to the user guide included with the cable or computer for handling instructions.

4



Turn on SELPHY.

- Press the ⏻ button to turn on SELPHY.

Windows

- When the installation finishes, click [Restart] to restart the computer and complete the installation.

5

Confirm that the software has been started properly.

- ▶ The software will start and the screen on the left will appear when a connection between SELPHY and the computer is established.
- Perform Steps 2 to 4 to automatically start the software the next time you use it.

Windows

- If the screen at the left does not appear, select from the [Start] menu ▶ [All Programs] or [Programs] ▶ [Canon Utilities] ▶ [SELPHY Photo Print] ▶ [SELPHY Photo Print].

Macintosh

- If the screen at the left does not appear, follow these steps to register your printer:
  After clicking [ ] in the menu, click [System Preferences], then [Print & Fax] to bring up the [Print & Fax] window. Click [+], select [CP780] from the pop-up window and click [Add].
  After you have finished registering your printer, click [SELPHY Photo Print] from the Dock (the bar at the bottom of the desktop), and the screen at the left will appear.

- SELPHY may not operate correctly if it is connected to a computer via a USB hub.
- SELPHY may not function properly if other USB devices (with the exception of a USB mouse or USB keyboard) are used at the same time. Disconnect any other USB devices from your computer and then reconnect SELPHY.
- Do not put your computer into the standby mode (or sleep mode) while SELPHY is connected to the computer's USB port. If you accidentally do so, awaken the computer from the standby mode without disconnecting the USB cable.
- For details on how to awaken the computer refer to the user guide provided with your computer.

Printing from Your Computer

Use the installed software (SELPHY Photo Print) to print images from the computer. If your computer is equipped with speakers, set the volume so that the audio guidance for necessary operations can be heard.

1

Display the print menu.

- Click [Print menu].
- If printing preparations are not complete (paper cassette and color ink cassette inserted), you cannot click the Print Menu. Follow the audio guidance or onscreen instructions to perform the necessary operations.

2

Select a print method.

- Click [Simple print].
- You can make prints with frames, stamps, and speech bubbles by clicking [Decoration print].
- You can make prints with calendars added by clicking [Calender print].

3

Select an image.

▶ Images will display in a list within the [My Pictures] folder in Windows, and the [Pictures] folder in Macintosh.

You can select the conditions for the images to display.

You can display images saved in another folder, if you press this button to select a folder from the screen that appears.

- Click the selected image for printing.

▶ The background color changes and the image is set for printing.

- Use the same procedures to click all images you want to print.
- If you click again, the background color switches back to the original color and the settings are canceled.

4



Press the - or + buttons to set the number of prints.

Select the number of prints.

- Select the number of copies for each image.
- Click [Print] to start printing.

Macintosh





- If paper is depleted, refill the paper cassette and perform the operations below to restart printing.

① Click on the Dock (the bar that appears at the bottom of the screen) and the screen at the left will appear (upper screen is 10.4, lower screen is 10.5).

② Click print jobs as shown on the left.

③ In 10.4 click [Start Jobs]. In 10.5 open the [Edit] menu and select [Select All], then click [Resume].

▶ Printing will restart.

5

Close the program.

Windows

- When all printing is finished, Click ☒ at the top right corner of the screen.

Macintosh

- When all printing is finished, Click ⊗ at the top left corner of the screen.

Printing From Your Digital Camera

Select and print images directly from a camera that supports the PictBridge standard. A Canon brand camera will be used as an example to explain the print method. If operations are different for the camera you use, refer to the user guide for your camera.

1

Check that there is no memory card inserted and that no computer is connected to SELPHY.

2



Insert the USB cable (included with the camera) into the camera and SELPHY.

3

First turn on SELPHY, then turn on the camera and play back the images on the camera.

▶ The icon will appear on the camera screen.

4

Select the desired image on the camera, and press the button of the camera.

▶ Printing starts.

- You cannot stop printing with the ▢(BACK) button. Use camera operations to stop printing.
- PictBridge is an industry standard established by the Camera & Imaging Products Association (CIPA). It allows any digital camera or video camera, regardless of the manufacturer or model, to print images taken with the camera directly to a printer without using a computer.

Printing Images Using Camera Specified Settings (DPOF Print)

Select images or specify print settings with the camera before printing. For details refer to the user guide provided with your camera.

1



Insert a memory card containing DPOF settings made with the camera into the memory card slot.

▶ The [DPOF images remain. Print images?] appears on the screen.

2

Press OK.

3



"Print type" set with the camera
: Index
: Standard

Number of sheets required

[Date] and [File No.] set with the camera

Check the settings.

4



Print.

● Press the button to start printing.

- The date and file number are the DPOF settings made with the camera (these settings cannot be changed with SELPHY).
- The screen in Step 3 can be also displayed when you press the ☐(MENU) button and select [DPOF Print], then press **OK**. [DPOF Print] only displays when a memory card is inserted that contains DPOF information set with the camera.

Turning Off the Information Displayed on the Screen

You can hide the image information and fully display the image on the screen.

1



Display the setting screen.

- Press the ▢(MENU) button.
- Press the ▲ or ▼ buttons to select [Printer Setup], then press **OK**.

2

Set [Info Display] to [Off].

- Press the ▲ or ▼ buttons to select [Info Display]
- Press the ◀ or ▶ buttons to select [Off], then press the ▢(BACK) to make the setting.
- Pressing the ▢(BACK) button again will restore the image display screen.

Changing the Date Style

You can change the order of the date (p. 18) when imprinting the date.

1



Display the settings screen.

- Press the ▢(MENU) button.
- Press the ▲ or ▼ buttons to select [Printer Setup], then press **OK**.

2



Make settings.

- Press the ▲ or ▼ buttons to select [Date Format]
- Press the ◀ or ▶ buttons to change the date format, then press the ▢(BACK) button to make the setting.
- Pressing the ▢(BACK) button again will restore the image display screen.

Using the Battery Pack

Use the (separately sold) battery pack NB-CP2L for printing images in places without power outlet. With a fully charged battery, you can print approximately 36 sheets of Postcard size paper.

1



Remove the battery cover.

- Slide and hold the cover lock towards ①, then remove the cover towards ②.

2



Remove the battery terminal cover.

3



Attach the battery.

- Insert the tab as shown in ① , then push as shown in ② until it clicks and locks into place.

4

Plug in SELPHY. (p. 11)

- ▶ Charging starts and ➔ appears on the screen.
- ▶ Charging completes after approximately 4 hrs. and ➔ disappears.
- If you press the ⏻ button while the battery is charging (p. 14), SELPHY can be used. When you turn off the power (p. 14), ➔ appears and charging resumes.

- For cautions concerning the battery refer to the user guide provided with the battery.
- When ➔ is displayed and you press any button other than the ⏻ button for 3 seconds or longer, ➔ will disappear. When the screen is turned off while the battery is charging and you press any button other than the ⏻ button, ➔ will appear after approximately 10 seconds.
- If SELPHY is idle for 5 minutes, the power turns off in order to save energy.

CAUTION
RISK OF EXPLOSION IF BATTERY IS REPLACED BY AN INCORRECT TYPE.
DISPOSE OF USED BATTERIES ACCORDING TO LOCAL REGULATION.

Printing From Your Mobile Phone

Use the (separately sold) Bluetooth Unit BU-30 for wirelessly printing images from Bluetooth enabled mobile phones. For details on how to use the mobile phone or on printing methods via Bluetooth refer to the user guide provided with the mobile phone.

1

Make sure that there is no memory card inserted and that no computer is connected to SELPHY.

2



Insert the Bluetooth unit.

- Remove the cover attached to BU-30, and insert it as shown.
- Turn on SELPHY. (p. 14)

3

Up to approx. 10 m (33 ft.)

Transfer images from your mobile phone to SELPHY.

- Bluetooth unit blinks blue during data transmission.
- ▶ Printing starts after data transmission is completed.

- You cannot establish a wireless connection between a computer and SELPHY.
- Only image data files up to approx. 2 MB can be transmitted (maximum data size varies depending on the mobile phone).
- Data transmission time increases when data size is large. Accordingly, it may take some time before printing starts.
- Movies, E-mails, phone directories, or image data, for example, downloaded from a URL attached to an E-mail may not be printable.
- Depending on the mobile phone model, images saved on the memory card may not be printed.
- Printing cannot be canceled by pressing the ▢(BACK) button during wireless printing. Use mobile phone operations to stop printing.
- SELPHY automatically sets the print orientation.
- Depending on the paper size you use, edges of the image may be cropped.

Select Canon CP780-XX:XX:XX (X stands for one digit) when selecting a target device name on your mobile phone.

Troubleshooting

If you think there is a problem with SELPHY, first check the following. If the items below do not solve your problem, contact a Canon Customer Support Help Desk as listed on the included customer support list.

Power

■ Power Will Not Turn On

- Confirm that the plug is connected. (p. 11)
- When using a (separately sold) battery, use a charged battery. (p. 29)
- Hold the ⏻ button pressed until the start-up image appears on the screen. (p. 14)

Printing Problems

■ Cannot Print

- Make sure that the color ink cassette and paper cassettes are correctly inserted. (p. 11)
- When the ink is spent replace the color ink cassette with a new one. When the paper is spent, refill the paper cassette with new paper. (p. 15)
- Are you using the correct combination of paper, paper cassette and color ink cassette? (p. 9)
- Is SELPHY connected to more than one device at once? Do not connect simultaneously to a camera, memory card or computer.
- Is the ink sheet slack? (p. 9)
- Make sure that you are using the dedicated paper. (p. 10)
- Depending on the room temperature SELPHY may overheat and temporarily stop operating. This is not a malfunction. Wait until the temperature drops and SELPHY resumes. If SELPHY is connected to a computer, a message will appear on the computer screen. Do not cancel the print. Wait until printing resumes.

Cannot print from memory card, image does not display

- Is the memory card inserted all the way into the slot with the label facing upward? (pp. 13, 14)
- Make sure you are using a supported image type. (p. 13)
- Have you inserted the memory card directly into the card slot without first inserting it into an adapter? (p. 13)

Printing from Cameras

- Is SELPHY connected to the camera correctly? (p. 26)
- Confirm that your camera supports PictBridge. (p. 26)

Printing from Computers

- Did you install the printer driver according to the correct procedures? (p. 22)
- Is SELPHY connected directly to a port on the computer with the USB cable?
- Problems Exclusive to Windows: Is the printer set to offline? If it is, Right-click the printer icon and cancel the offline setting.
- Problems Exclusive to Macintosh: Is SELPHY registered on the Printer List?

■ Cannot Print the Date

Printing from Memory Cards

- Is the date imprint option set? (p. 18)
  If you are using DPOF printing, the date imprint settings are configured on the camera used for the DPOF settings.

Printing from mobile phones

- When using Bluetooth, the date will not be printed.

Printing from Cameras

- Confirm that the date setting in your camera is set to [On]. However, if the setting is [Default], the date imprint settings of SELPHY will be used.

■ Cannot Make Clean Prints

- Is the ink sheet or paper dusty?
- Is dust lodged within SELPHY? (p. 33)
- Has condensation formed within SELPHY? (p. 33)
- Is SELPHY placed near a device with a strong electromagnetic or magnetic field? (p. 8)

■ Colors on the Computer Display and the Print are Different

- Color generation methods are different with computer screens and prints. Moreover, the variance may be attributable to the environment in which the screen is viewed (color and strength of the light), or to the screen's color adjustment settings.

■ After using the computer to cancel a print in progress, an image that had already been printed was printed again when printing resumed.

- When you restart printing on a Macintosh computer after canceling, an already printed image may print again when printing resumes.

Paper Problems

■ Paper Will Not Fit into Cassette

- Does the paper size match the size of the paper cassette? (p. 4)

■ Paper is Not Feeding Properly

- Check the paper and paper cassette are correctly inserted. (p. 11)

■ Frequent Paper Jams

- Has too much paper been placed in the paper cassette?
  Do not place 19 or more sheets in the cassette (13 or more for Wide size).
- Have 19 or more sheets (13 or more for Wide size) collected on top of the paper cassette?
- Make sure that you are using the dedicated paper. (p. 10)

■ Cannot Print the Specified Number of Prints. Paper Left Over

- Actions like the following will consume ink sheet capacity: repeatedly turning SELPHY on and off without printing, canceling print in progress, pulling on the ink sheet and taking out the ink cassette when the paper runs out while printing multiple copies. Do not remove the ink cassette when you remove and refill the paper cassette.

Error Messages

If a problem occurs with SELPHY, a message and a possible solution appear on the screen. In this section you can find solutions for problems when no solution is provided with the message. If a problem occurs while SELPHY is connected to the camera, the camera may also display an error message. Be sure to check both devices.

■ No paper, or cassette incorrectly inserted!

- Make sure that the paper cassette is correctly inserted. (p. 11)
- When the paper is spent, refill the paper cassette with new paper. (p. 9)

- If the paper is not feeding correctly into SELPHY, remove the paper cassette and any paper stuck inside SELPHY. Then reinsert the paper cassette.

■ Paper jam!

- If the paper will not come out even when the power is turned off and back on, contact a Canon Customer Support Help Desk.
- Was paper left at the back of SELPHY during printing?

■ There is a problem with the color ink cassette!

- Remove and reinsert the color ink cassette. (pp. 11, 15) However, if you cannot remove the color ink cassette, contact a Canon Customer Support Help Desk.

■ Cannot read data from memory card!

- Image types that are not supported cannot be printed. (p. 13) Press the ▢(BACK) button to return to the original screen.

■ Communication error!

- SELPHY cannot connect to the mobile phone. (p. 30) Press the ▢(BACK) button to restore the original screen.

■ No images on card!

- Check to see if the memory card is properly inserted all the way into the slot. (p. 14)
- Make sure you are using a supported image type. (p. 13)

■ Error!

- Turn the printer's power off and turn it on again. If the error message continues to display, contact a Canon Customer Support center for assistance.

Handling Precautions

- Do not apply excessive force to the printer. Force or impact on the printer may result in paper jams or equipment damage.
- Do not turn the power on and off repeatedly when you do not intend to print.
  The initialization process consumes ink and the equivalent of several pages could be wasted.
- Be careful not to spray the equipment with insecticides or volatile substances. In addition, do not store the equipment in contact with rubber or vinyl products for long periods of time. This may cause alteration of the casing.
- Depending on the room temperature, SELPHY may overheat and temporarily stop operating. This is not a malfunction. SELPHY will resume normal printing as soon as it cools down. Temporary stoppages increase printing time and are most likely to occur when printing continuously, if a room is unusually warm, if the air vents on the back of SELPHY are blocked and internal temperature is high.
- Avoid condensation on the equipment when moving it from a cold to a hot place, by putting it in an airtight, sealable plastic bag and allow for adjustment to temperature changes gradually before removing from the bag. In the event that condensation does form within the equipment, keep it at room temperature until the water droplets evaporate naturally before use.
- When SELPHY gets dirty, wipe the casing with a soft dry cloth.
- When dust or dirt has accumulated on the battery cover or vent (pp. 6, 29), be sure to remove the color ink cassette (p. 15) before cleaning. If dust gets in through the vent, the printer may not print cleanly.

Never wipe using volatile solvents such as benzine, paint thinner, or diluted neutral solvent. They may cause deformation or peeling of the casing.

Specifications

All data is measured according to standard Canon testing procedures. We reserve the right to change specifications without notice.

SELPHY CP780

Printing Method	Dye-sublimation thermal transfer (with overcoating)	
Print Resolution	300 x 300 dpi	
Gradation	256 shades per color	
Ink	Dedicated color ink cassette (Y/M/C/overcoating)	
Paper	Postcard Size, L Size, Card Size (including full page label sheets, 8-label sheets), Wide Size	
Print Size	**Borderless**	**Bordered**
Postcard Size	100.0 x 148.0 mm (3.94 x 5.83 in.)	91.4 x 121.9 mm (3.60 x 4.80 in.)
L Size	89.0 x 119.0 mm (3.50 x 4.69 in.)	79.2 x 105.3 mm (3.12 x 4.15 in.)
Card Size	54.0 x 86.0 mm (2.13 x 3.39 in.)	50.0 x 66.7 mm (1.97 x 2.63 in.)
(per label)	22.0 x 17.3 mm (0.87 x 0.68 in.)	
Wide Size	100.0 x 200.0 mm (3.94 x 7.87 in.)	91.4 x 121.9 mm (3.60 x 4.80 in.)
Printing Speed*1	**Printing from Memory Cards/Connected to Cameras with PictBridge**	
Postcard Size	Approx. 47 sec.	
L Size	Approx. 39 sec.	
Card Size	Approx. 24 sec.	
Wide Size	Approx. 60 sec.	
Feeding System	Automatic paper feed from paper cassette	
Ejection System	Automatic paper ejection on top of paper cassette	
Screen	2.5-inch type, TFT LCD color Monitor	
Interface		
USB	Connecting to a PictBridge compliant device: USB compliant Type A connector Connecting to a computer: USB compliant Type B connector	
Wireless	Bluetooth*2	
Memory Cards	CF (CompactFlash) Card, Microdrive, xD-Picture Card*3, SD Memory Card, miniSD Card, SDHC Memory Card, miniSDHC Card, MultiMediaCard, MMCplus Card, HC MMCplus Card, MMCmobile Card, RS-MMC Card, microSD Card*3, microSDHC Card*3, MMCmicro Card*3, Memory Stick, Memory Stick PRO, Memory Stick Duo, Memory Stick PRO Duo, Memory Stick micro*3	
Operating Temperatures	5 – 40°C (41 – 104°F)	
Operating Humidity	20 – 80%	
Power Source	Compact Power Adapter CA-CP200 W Battery pack NB-CP2L (sold separately)	
Power Consumption	60 W or less (4 W or less on standby)	
Dimensions	176.0 x 132.6 x 75.6 mm (6.93 x 5.22 x 2.98 in.)	
Weight (printer only)	Approx. 940g (approx. 33.2 oz.)	

*1 Measured from start of the yellow printing pass to final output.

*2 Bluetooth Unit BU-30 (sold separately) is required.

*3 Dedicated adapter (commercially available) is required.

Compact Power Adapter CA-CP200 W

Rated Input	100 - 240 V AC (50/60 Hz) 1.5 A (100 V) - 0.75 A (240 V)
Rated Output	24 V DC, 2.2 A
Dimensions	122.0 x 60.0 x 30.5 mm (4.80 x 2.36 x 1.20 in.) (excluding power cord)
Operating Temperatures	0 - 45°C (32 - 113°F)
Weight	Approx. 310 g (10.9 oz.)

As an ENERGY STAR Partner, Canon Inc. has determined that this product meets the ENERGY STAR guidelines for energy efficiency.
For voltages of 100 to 120V only.

USA and Canada only:
The Lithium ion/polymer battery is recyclable.
Please call 1-800-8-BATTERY for information on how to recycle this battery.

FCC Notice

(Printer, Model CD1060 Systems)

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:
(1) This device may not cause harmful interference, and
(2) this device must accept any interference received, including interference that may cause undesired operation.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation.
This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

The cable with the ferrite core provided with the printer must be used with this equipment in order to comply with Class B limits in Subpart B of Part 15 of the FCC rules.

Do not make any changes or modifications to the equipment unless otherwise specified in the manual. If such changes or modifications should be made, you could be required to stop operation of the equipment.

Canon U.S.A., Inc.
One Canon Plaza, Lake Success, NY 11042, U.S.A.
Tel No. (516) 328-5600

Canadian Radio Interference Regulations

This Class B digital apparatus complies with Canadian ICES-003.

Trademark Acknowledgments

- The SDHC logo and miniSDHC logo are trademarks.
- Portions of the code used in this firmware are based in part on the work of the Independent JPEG Group.

About This Guide

- Reprinting, transmitting, or storing in a retrieval system any part of this guide without the permission of Canon is prohibited.
- Canon reserves the right to change the contents of this guide at any time without prior notice.
- Illustrations and screenshots in this guide may differ slightly from the actual equipment.
- Every effort has been made to ensure that the information contained in this guide is accurate and complete. However, if you notice any errors or omissions, please contact the Canon Customer Support Help Desk indicated on the customer support list included with the product.
- The above items notwithstanding, Canon accepts no liability for damages due to mistaken operation of the products.

This product is designed to achieve excellent performance when used with genuine Canon accessories. Canon shall not be liable for any damage to this product and/or accidents such as fire, etc., caused by the malfunction of non-genuine Canon accessories (e.g., a leakage and/or explosion of a battery pack). Please note that this warranty does not apply to repairs arising out of the malfunction of non-genuine Canon accessories, although you may request such repairs on a chargeable basis.

CDI-E394-040 ©CANON INC.2009 PRINTED IN CHINA

Made in China C86-1159

Canon

COMPACT PHOTO PRINTER

Solution Disk

Ver. 18.1

J
E
F
S

For Macintosh

Canon Utilities
SELPHY Photo Print 1.0
CP780 Printer Driver 4.4
(for Mac OS X)

For Windows

Canon Utilities
SELPHY Photo Print 1.0
CP780 Printer Driver 4.6
(for Windows Vista x64)

C 28-01

C86-1159

COMPACT disc

Windows Vista are trademarks or registered trademarks of Microsoft Corporation in the United States and/or other countries. Macintosh and Mac OS are trademarks of Apple Inc., registered in the U.S. and other countries.

Remove this sheet before putting paper in the paper cassette.

Veillez à retirer cette feuille de protection avant toute impression.

Bitte entfernen Sie dieses Blatt, bevor Sie das Papier in die Papierkassette legen.

Retire esta protección antes de colocar el papel en el casette.

Rimuovere questo foglio prima di inserire la carta nel cassetto.

これは保護シートです。
ペーパーカセットにペーパーを設置する前に取り除いて下さい。

将纸张放入纸匣之前，请将此片取出。

將紙張放入紙匣前，請將保護紙撕掉。

Made in Japan / Fabriqué Japon / Hergestellt in Japan /
Prodotto in Giappone / Hecho en Japón / 日本制造 / 日本製造

Canon

CDI-M435

Canon Customer Support

Canon U.S.A., Inc.
Canon Customer Care Center
Phone (US): 1-800-828-4040 (Available Mon. - Fri., 9 AM to 8 PM Eastern Time)
www.powershot.com
Manuals available for download:
http://www.powershot.com/powershot2/customer/manual.html

Canon Canada Inc.
Phone (Canada): 1-800-OK-CANON (1-800-652-2666) (24 hours/day, 7 days/week)
Manuals available for download:
http://www.canon.ca (Go to "Customer Support")

English

- The warranty of the product(s) is effective only in the country written on your warranty certificate.
- Please safekeep this sheet as it contains important information.

Español

- La garantía del producto o productos es válida sólo en el país que aparece escrito en su certificado de garantía.
- Guarde este impreso en lugar seguro ya que contiene información importante.

Français

- La garantie de ce ou ces produits n'est valide que dans le pays indiqué sur votre certificat de garantie.
- Veuillez conserver cette feuille car elle contient d'importantes informations.

Online product registration for U.S.A. Customers only.

Register your product online at www.powershot.com/productregistration *and*...

✓ **Receive firmware and software upgrades**
Canon USA often updates the software and firmware for its digital photography products. You will be among the first ones to receive the notifications.

✓ **Protect your product**
We will keep the model number and date of purchase of your new Canon product on file to help you refer to this information in the event of an insurance claim such as loss or theft.

✓ **Receive information on new products and promotions**
Upon your request, we will send you information on Canon new products and promotions.

CDI-M435-010
© 2008 CANON INC.
PRINTED IN CHINA
IMPRIMÉ EN CHINE

Online product registration for Canadian Customers only.

Register your product online at www.canon.ca/product_registration *and*...

- ✓ **Receive firmware and software upgrades**
  Canon Canada updates software and firmware for its digital photography products. You will be among the first ones to receive the notifications.
- ✓ **Receive the latest product and promotion info.**
  Upon your request, we will send you information on new Canon products and promotions.
- ✓ **As a valued customer, you will be notified**
  Canon prides itself on being proactive, so rest assured you will be emailed any important information relating specifically to your product.

Enregistrement de produits en ligne pour les clients canadiens seulement.

Enregistrez votre produit en ligne à www.canon.ca/product_registration *et*...

- ✓ **Recevez les mises à niveau de microprogrammation et de logiciels**
  Canon Canada met à jour la microprogrammation et les logiciels de ses produits de photographie numérique. Vous serez parmi les premières personnes à recevoir les notifications correspondantes.
- ✓ **Recevez les renseignements les plus récents sur les produits et les promotions**
  Sur demande, nous vous ferons parvenir des renseignements sur les nouveaux produits et promotions Canon.
- ✓ **En tant que membre de notre estimée clientèle, vous recevrez une notification**
  Étant donné que Canon mise sur une approche proactive, vous pouvez être certain(e) que vous recevrez par courriel tous les renseignements importants relatifs à votre produit.

CANON® Card Photo Printer Limited Warranty – For U.S.A. & Canada Only

The limited warranty set forth below is given by Canon U.S.A., Inc. in the United States and Canon Canada Inc. in Canada with respect to the Canon-brand Card Photo Printer (the "Product") purchased with this limited warranty, when purchased and used in the United States or Canada. This limited warranty only applies to the Product packaged with this limited warranty. Canon U.S.A., Inc. and Canon Canada Inc. will be referred to collectively herein as "Canon."

The Product, when delivered to you in new condition in its original container, is warranted against defects in materials and workmanship under normal use and service for a period of one (1) year from the date of original purchase. Defective parts or a defective Product returned to Canon, or an Authorized Service Center, and proven to be defective upon inspection, will be repaired with new or comparable rebuilt parts or exchanged for a refurbished Product as determined by Canon or the Authorized Service Center. Warranty replacement shall not extend the original warranty period. This warranty does not cover any accessories, nor does it cover any consumables, such as paper or ink cartridges, as to which there shall be no warranty or replacement.

This limited warranty shall only apply if the Product is used in conjunction with compatible computers, peripheral equipment and software, as to which items Canon shall have no responsibility. **Non-Canon brand equipment and software that may be distributed with the Product are sold "as is" and without warranty of any kind by Canon, including any implied warranty or condition regarding merchantability or fitness for a particular purpose, and all such warranties and conditions are disclaimed. The sole warranty, if any, with respect to such non-Canon brand items is given by the manufacturer or producer thereof.**

This limited warranty covers all defects encountered in normal use of the Product and does not apply in the following cases:

(a) Loss of or damage to the Product due to abuse, neglect, mishandling, improper packaging by you, alteration, accident, electrical current fluctuations, improper use, failure to following operating maintenance or environmental conditions prescribed in Canon's user's manual or other documentation, or services performed by someone other than Canon or its Authorized Service Center. Without limiting the foregoing, water damage, sand/corrosion damage, battery leakage, dropping the printer, scratches, and abrasions will be presumed to have resulted from misuse, abuse or failure to operate the Product as set forth in the operating instructions.
(b) Use of parts or supplies (other than those sold by Canon) that cause damage to the Product or cause abnormally frequent service calls or service problems.
(c) Use of supplies or parts (other than those distributed by Canon).
(d) If the Product has had it serial number or dating defaced, altered or removed.
(e) If the Product is used for commercial or industrial use.

NO IMPLIED WARRANTY, INCLUDING ANY IMPLIED WARRANTY OR CONDITION OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE, APPLIES TO THE PRODUCT AFTER THE APPLICABLE PERIOD OF THE EXPRESS LIMITED WARRANTY STATED ABOVE, AND NO OTHER EXPRESS WARRANTY, GUARANTY OR CONDITION, EXCEPT AS MENTIONED ABOVE, GIVEN BY ANY PERSON OR ENTITY WITH RESPECT TO THE PRODUCT SHALL BIND CANON, OR ITS AUTHORIZED SERVICE CENTER. (SOME STATES AND PROVINCES DO NOT ALLOW LIMITATIONS ON HOW LONG AN IMPLIED WARRANTY LASTS, SO THE ABOVE LIMITATION MAY NOT APPLY TO YOU.) CANON SHALL NOT BE LIABLE FOR LOSS OF REVENUES OR PROFITS, INCONVENIENCE, EXPENSE FOR SUBSTITUTE EQUIPMENT OR SERVICE, STORAGE CHARGES, LOSS OR CORRUPTION OF DATA, OR ANY OTHER SPECIAL, INCIDENTAL OR CONSEQUENTIAL DAMAGES CAUSED BY THE USE, MISUSE, OR INABILITY TO USE THE PRODUCT REGARDLESS OF THE LEGAL THEORY ON WHICH THE CLAIM IS BASED, AND EVEN IF CANON, OR ITS AUTHORIZED SERVICE CENTER HAS BEEN ADVISED OF THE POSSIBILITY OF SUCH DAMAGES. NOR SHALL RECOVERY OF ANY KIND AGAINST CANON, OR ITS AUTHORIZED SERVICE CENTER, BE GREATER IN AMOUNT THAN THE PURCHASE PRICE OF THE PRODUCT CAUSING THE ALLEGED DAMAGE. WITHOUT LIMITING THE FOREGOING, YOU ASSUME ALL RISK AND LIABILITY FOR LOSS, DAMAGE OR INJURY TO YOU AND YOUR PROPERTY AND TO OTHERS AND THEIR PROPERTY ARISING OUT OF THE POSSESSION, USE, MISUSE, OR INABILITY TO USE THE PRODUCT SOLD BY CANON NOT CAUSED SOLELY AND DIRECTLY BY THE NEGLIGENCE OF CANON, OR ITS AUTHORIZED SERVICE CENTER. (SOME STATES AND PROVINCES DO NOT ALLOW THE EXCLUSION OR LIMITATION OF INCIDENTAL OR CONSEQUENTIAL DAMAGES, SO THE ABOVE EXCLUSION OR LIMITATION MAY NOT APPLY TO YOU.) THIS LIMITED WARRANTY SHALL NOT EXTEND TO ANYONE OTHER THAN THE ORIGINAL PURCHASER OF THE PRODUCT OR THE PERSON FOR WHOM IT WAS PURCHASED AS A GIFT, AND STATES YOUR EXCLUSIVE REMEDY.

For Products Purchased in the U.S.A.
You may obtain technical support for your Product as follows:
- E-mail support via our Web Site at **www.usa.canon.com**
- Telephone assistance from a Canon U.S.A. Customer Care representative free of charge during regular business hours (currently Monday-Friday 9:00 a.m.-8:00 p.m. EST, excluding holidays) at **1-800-828-4040 or 1-800-OK-CANON (1-800-652-2666).**

For Products Purchased in Canada
You may obtain technical support for your Product as follows:
- Telephone assistance from a Canon Canada Customer Care representative free of charge during regular business hours (currently Monday-Friday 9:00 a.m.-8:00 p.m. EST, excluding holiday) at **1-800-OK-CANON (1-800-652-2666).**

Have your Product serial number and your date of purchase available when you make the call to expedite service. A Canon Customer Care representative will attempt to diagnose the nature of the problem and correct it over the telephone. If the problem cannot be corrected over the telephone, you will be asked to follow the applicable procedures for MAIL-IN SERVICE. Note that a dated proof of purchase is required at the time of service. This requirement will be satisfied by providing a copy of your dated bill of sale.

*Technical support program specifics subject to change without notice.

MAIL-IN SERVICE

MAIL-IN SERVICE is a program under which your Product is repaired by a Canon U.S.A. or a Canon Canada Authorized Service Center. You will be given the name, address and phone number of an Authorized Service Center, by contacting the Canon U.S.A. Customer Care Center at 1-800-828-4040 or Canon Canada Customer Information Centre at 1-800-OK-CANON (1-800-652-2666). It is your responsibility to properly package and send the defective Product together with a copy of your dated proof of purchase, a complete explanation of the problem and a return address to the Authorized Service Center at your expense. Do not include any other items with the defective Product. The defective Product covered by this limited warranty will be repaired and returned to you without charge by the Authorized Service Center. Any Product received by the Authorized Service Center that is not covered by the limited warranty will be returned unrepaired, or, at the discretion of the Authorized Service Center, you may receive a written estimate of repair at such cost as the Authorized Service Center may establish from time to time.

This limited warranty gives you specific legal rights, and you may also have other rights, which vary from state to state (or province to province in Canada).

Canon U.S.A., Inc.
One Canon Plaza
Lake Success, NY 11042
USA
(The above address is not to be used for the MAIL-IN SERVICE program)

Canon Canada Inc.
6390 Dixie Road
Mississauga, Ontario L5T 1P7
Canada
(The above address is not to be used for the MAIL-IN SERVICE program)

® 2007 Canon U.S.A., Inc. Canon is a registered trademark of Canon Inc.
All brand or product names are registered trademarks or trademarks of their respective owners.

CANON LIMITED WARRANTY

CANON U.S.A., INC. CANON CANADA INC.

NAME
NOM

ADDRESS
ADRESSE

CITY
VILLE

PROVINCE

POSTAL CODE
CODE POSTAL

THIS WARRANTY CARD AND YOUR BILL OF SALE MUST BE PRESENTED FOR WARRANTY SERVICE.

CETTE CARTE DE GARANTIE ET VOTRE PREUVE D'ACHAT DOIVENT ÊTRE PRÉSENTÉS POUR RECEVOIR LE SERVICE SOUS GARANTIE.

DEALER'S NAME & ADDRESS
MARCHAND NOM & ADRESSE

MODEL
MODELE SELPHY CP780

BODY NO.
BOITIER NO [redacted]

PURCHASE DATE
DATE D'ACHAT / /

CDW-M012-010

PRINTED IN CHINA
IMPRIMÉ EN CHINE

Dealer Record of Canon Purchase
Fiche d'Achat pour Concessionnaire Canon

Complete this card at time of sale.
A remplir au moment de l'achat

PRESENT OWNERSHIP AND PRODUCTS INTERESTED IN
Articles déjà en possession ou jugés dignes d'intérêt

			OWNS En Possession	INTERESTED IN Intéressé par
CAMERAS / APPAREILS PHOTO	(Camera) (Appareil)	(Lens) (Objectif)	•	•
	(Camera) (Appareil)	(Lens) (Objectif)	•	•

INTERCHANGEABLE LENS Objectif interchangeable	OWNS En possession	INTERESTED IN Intéressé par	OTHER ACCESSORIES Autres accessoires	OWNS En possession	INTERESTED IN Intéressé par
	•	•		•	•

MODEL Modèle	SELPHY CP780	SERIAL NO. No. de série	[redacted]

U.S.A. & Canada only

CUSTOMER
Client

NAME
Nom

ADDRESS
Adresse

CITY/STATE
Ville/Province

ZIP
Code postal

PHONE
Téléphone

Canon

Garantie restreinte des imprimantes photo carte de CANON® – Pour les États-Unis et le Canada seulement

La présente garantie restreinte est fournie par Canon U.S.A., Inc. aux États-Unis et Canon Canada Inc. au Canada à l'égard des imprimantes photo carte de marque Canon (le « Produit ») achetées et couvertes par ladite garantie restreinte, lorsqu'elles sont achetées et utilisées aux États-Unis ou au Canada. La présente garantie restreinte s'applique uniquement au Produit emballé avec ladite garantie restreinte. Canon U.S.A., Inc. et Canon Canada Inc. seront désignées collectivement sous le nom de « Canon ».

Le Produit, lorsqu'il vous est livré à l'état neuf dans son emballage d'origine, est garanti contre tout vice de matière et de fabrication, dans des conditions d'utilisation et de service normales, pendant une période d'un (1) an à compter de la date de l'achat initial. Les pièces défectueuses ou un Produit défectueux qui sont retournés à Canon ou à un centre d'entretien et après-vente autorisé, et dont l'inspection confirme une défectuosité, seront réparés à l'aide de nouvelles pièces ou remises à neuf comparables, ou échangés contre un Produit remis à neuf, tel que déterminé par Canon ou le centre d'entretien et après-vente autorisé. La période de garantie pour le remplacement ne peut dépasser la période de garantie initiale. La présente garantie restreinte ne s'applique pas aux accessoires ni aux consommables, tels que le papier ou les cartouches d'encre, pour lesquels il n'y a pas de garantie ni de remplacement.

La présente garantie restreinte s'applique uniquement si le Produit est utilisé conjointement avec des ordinateurs équipement périphérique et des logiciels compatibles, pour lesquels Canon n'assume aucune responsabilité. **L'équipement et les logiciels de marque autre que Canon qui peuvent être distribués avec le Produit sont vendus « tels quels », sans garantie d'aucune sorte par Canon, y compris toute garantie implicite ou condition à l'égard de la qualité marchande ou de l'aptitude à une fin particulière. De telles garanties et conditions ne sont pas reconnues par Canon. La seule garantie, si garantie il y a, liée à un article d'une marque autre que Canon, est donnée par le fabricant ou le producteur de cet article.**

La présente garantie restreinte couvre toutes les défectuosités constatées pendant l'utilisation normale du Produit et ne s'applique à aucun des cas suivants :

(a) perte ou endommagement du Produit, causé par l'usage abusif, la négligence, la manipulation inadéquate, l'emballage inadéquat fait par vous, les modifications, les accidents et les variations de courant électrique, ainsi que l'omission d'observer les directives à l'égard du mode d'utilisation, des conditions d'entretien et du milieu ambiant énoncées dans le manuel d'utilisation de Canon ou dans d'autres documents, ou les services effectués ailleurs que chez Canon ou dans son centre d'entretien et après-vente autorisé. De tels dommages comprennent, mais sans s'y limiter, les dommages causés par l'eau, le sable / la corrosion, la fuite des piles, la chute de l'imprimante, les égratignures et l'abrasion, dommages que l'on présume découler d'un usage impropre, d'un usage abusif ou de l'impossibilité d'utiliser le Produit selon les directives d'utilisation ;
(b) utilisation de pièces ou de fournitures (autres que celles vendues par Canon) ayant pour effet d'endommager le Produit ou d'entraîner une fréquence anormale d'appels d'entretien ou de problèmes nécessitant le recours au service d'entretien et après-vente ;
(c) utilisation de pièces ou de fournitures (autres que celles distribuées par Canon) ;
(d) modification ou retrait du numéro de série ou de la datation du Produit ;
(e) utilisation du Produit à des fins commerciales ou industrielles.

AUCUNE GARANTIE IMPLICITE, Y COMPRIS TOUTE GARANTIE IMPLICITE OU CONDITION À L'ÉGARD DE LA QUALITÉ MARCHANDE OU DE L'APTITUDE À UNE FIN PARTICULIÈRE, NE S'APPLIQUE AU PRODUIT APRÈS LA PÉRIODE PRESCRITE DE LA GARANTIE EXPRESSE RESTREINTE SUSMENTIONNÉE ET, À L'EXCEPTION DE LADITE GARANTIE EXPRESSE RESTREINTE, AUCUNE AUTRE GARANTIE EXPRESSE NI AUCUNE AUTRE CONDITION OU GARANTIE ACCORDÉE PAR TOUTE PERSONNE OU ENTITÉ À L'ÉGARD DU PRODUIT N'AURA POUR EFFET DE LIER CANON OU SON CENTRE D'ENTRETIEN ET APRÈS-VENTE AUTORISÉ À TOUTE OBLIGATION, QUELLE QU'ELLE SOIT. (CERTAINS ÉTATS ET CERTAINES PROVINCES N'AUTORISENT AUCUNE RESTRICTION SUR LA DURÉE D'UNE GARANTIE IMPLICITE ; AINSI, IL EST POSSIBLE QUE LA RESTRICTION ÉNONCÉE CI-DESSUS NE S'APPLIQUE PAS DANS VOTRE CAS.) CANON N'ASSUME AUCUNE RESPONSABILITÉ À L'ÉGARD DE LA PERTE DE PRODUITS D'EXPLOITATION OU DE PROFITS, NI À L'ÉGARD DES INCONVÉNIENTS ET DES FRAIS ENGAGÉS POUR DE L'ÉQUIPEMENT DE REMPLACEMENT, DES SERVICES D'ENTRETIEN ET APRÈS-VENTE, POUR L'ENTREPOSAGE, LA PERTE OU LA CORRUPTION DE DONNÉES, NI À L'ÉGARD DE TOUT DOMMAGE SPÉCIAL, INDIRECT OU ACCESSOIRE DÉCOULANT DE L'USAGE OU DE L'USAGE IMPROPRE, OU DE L'IMPOSSIBILITÉ D'UTILISER LE PRODUIT, QUELLE QUE SOIT L'ARGUMENTATION JURIDIQUE SUR LAQUELLE S'APPUIE LA DEMANDE, ET MÊME SI CANON OU SON CENTRE D'ENTRETIEN ET APRÈS-VENTE AUTORISÉ ONT ÉTÉ INFORMÉS DE LA POSSIBILITÉ DE TELS DOMMAGES. EN AUCUN CAS, AUCUN RECOUVREMENT, QUELLE QU'EN SOIT LA FORME, CONTRE CANON OU SON CENTRE D'ENTRETIEN ET APRÈS-VENTE AUTORISÉ NE SERA SUPÉRIEUR AU MONTANT DU PRIX D'ACHAT DU PRODUIT À L'ORIGINE DES DOMMAGES PRÉSUMÉS. SANS VOUS LIMITER À CE QUI PRÉCÈDE, VOUS ASSUMEZ TOUS LES RISQUES ET TOUTE LA RESPONSABILITÉ À L'ÉGARD DES PERTES, DES DOMMAGES MATÉRIELS ET DES BLESSURES CORPORELLES SUBIS PAR VOUS, VOTRE PROPRIÉTÉ OU D'AUTRES PERSONNES OU LEUR PROPRIÉTÉ EN RAISON DE LA POSSESSION, DE L'USAGE, DE L'USAGE IMPROPRE, OU DE L'IMPOSSIBILITÉ D'UTILISER LE PRODUIT VENDU PAR CANON, À MOINS QUE LESDITS DOMMAGES MATÉRIELS, PERTES ET BLESSURES CORPORELLES N'AIENT ÉTÉ CAUSÉS DIRECTEMENT ET EXCLUSIVEMENT PAR LA NÉGLIGENCE DE CANON OU DE SON CENTRE D'ENTRETIEN ET APRÈS-VENTE AUTORISÉ. (CERTAINS ÉTATS ET CERTAINES PROVINCES N'AUTORISENT AUCUNE EXCLUSION NI RESTRICTION DES DOMMAGES ACCESSOIRES OU INDIRECTS ; AINSI, IL EST POSSIBLE QUE LA RESTRICTION OU L'EXCLUSION ÉNONCÉE CI-DESSUS NE S'APPLIQUE PAS DANS VOTRE CAS.) LA PRÉSENTE GARANTIE RESTREINTE N'EST PAS ACCORDÉE À D'AUTRES PERSONNES QUE L'ACHETEUR INITIAL DU PRODUIT OU LA PERSONNE QUI A REÇU LEDIT PRODUIT EN CADEAU ET CONSTITUE VOTRE RECOURS EXCLUSIF.

Pour les produits achetés aux États-Unis

Vous pouvez obtenir un soutien technique pour votre Produit comme suit :
- Soutien courriel par l'intermédiaire de notre site Web, à **www.usa.canon.com**
- Assistance téléphonique auprès d'une représentante ou d'un représentant du Centre de renseignements clientèle de Canon U .S.A., sans frais, durant les heures normales d'ouverture (actuellement du lundi au vendredi, de 9 h à 20 h, HNE, à l'exclusion des jours fériés) au **1 800 828-4040 ou 1 800 OK CANON (1 800 652-2666)**.

Pour les produits achetés au Canada

Vous pouvez obtenir un soutien technique pour votre Produit comme suit :
- Assistance téléphonique auprès d'une représentante ou d'un représentant du Centre de renseignements clientèle de Canon Canada, sans frais, durant les heures normales d'ouverture (actuellement du lundi au vendredi, de 9 h à 20 h, HNE, à l'exclusion des jours fériés) au **1 800 OK CANON (1 800 652-2666)**.

Lors de l'appel, assurez-vous d'avoir le numéro de série du Produit et la date d'achat à portée de la main afin d'accélérer le service. Une représentante ou un représentant du Centre de renseignements clientèle de Canon tentera, le cas échéant, de déterminer la nature du problème et de résoudre celui-ci par téléphone. S'il est impossible de résoudre le problème par téléphone, on vous priera de vous conformer à la procédure applicable pour le SERVICE POSTAL. Veuillez noter qu'une preuve d'achat datée est requise lors du service d'entretien et après-vente. Il suffit de fournir une copie de votre acte de vente daté.

* Les détails du programme de soutien technique sont sujets à changement sans préavis.

SERVICE POSTAL

Le SERVICE POSTAL est un programme selon lequel les réparations de votre Produit sont effectuées par un centre d'entretien et après-vente autorisé de Canon U.S.A. ou de Canon Canada. On **vous fournira le nom, l'adresse et le numéro de téléphone d'un centre d'entretien et après-vente autorisé lorsque vous communiquerez avec le Centre d'information à la clientèle de Canon U.S.A.** au 1 800 828-4040 ou au Centre d'information à la clientèle de Canon Canada au 1 800 OK CANON (1 800 652-2666). Il vous incombe d'emballer adéquatement le Produit défectueux et de le faire parvenir, à vos frais, accompagné d'une copie de votre preuve d'achat datée, d'une explication détaillée du problème et d'une adresse de retour, au centre d'entretien et après-vente autorisé. Veuillez ne pas inclure d'autres articles avec le Produit défectueux. Le Produit défectueux couvert par la présente garantie restreinte sera réparé et vous sera retourné sans frais par le centre d'entretien et après-vente autorisé. Tout Produit reçu par le centre d'entretien et après-vente autorisé qui n'est pas couvert par la présente garantie restreinte vous sera retourné, sans aucune réparation ou, à la discrétion du centre d'entretien et après-vente autorisé, vous pourrez recevoir une estimation écrite des réparations selon le tarif que le centre d'entretien et après-vente autorisé peut établir à l'occasion.

La présente garantie restreinte vous accorde des droits particuliers reconnus par la loi et il se peut que vous disposiez d'autres droits qui varient d'un État à l'autre (ou d'une province à l'autre au Canada).

Canon U.S.A., Inc.
One Canon Plaza
Lake Success, NY 11042
É.-U.
(L'adresse ci-dessus ne doit pas être utilisée dans le cadre du programme de SERVICE POSTAL.)

Canon Canada Inc.
6390 ch Dixie
Mississauga ON L5T 1P7
Canada
(L'adresse ci-dessus ne doit pas être utilisée dans le cadre du programme de SERVICE POSTAL.)

® Canon U.S.A., Inc., 2007. Canon est une marque déposée de Canon Inc.
Tous les noms de marques ou de produits sont des marques déposées ou des marques de commerce de leurs propriétaires respectifs.

REMARKS

REMARKS